

## PEKUTHERM<sup>®</sup> AS A SCREW-PULL AID DIRECTIONS

1. Separate tool from machine nozzle or end of extruder.
2. While still at processing temperature, providing temperature is between 374° and 572° F, follow the last of the outgoing material with Pekutherm<sup>®</sup>, continuing to add small amounts of Pekutherm<sup>®</sup> until it exits clean or white from the machine nozzle or end of machine.
3. Continue to attempt to expel last amounts of Pekutherm<sup>®</sup> until no more material can be expelled. The Pekutherm<sup>®</sup> has now pre-scrubbed the screw and barrel and removed the material from the matrix (space) in between. The screw should now come out easily.
4. Follow all manufacturer's instructions to remove the screw from the barrel. (Again, this should be easy since there is nothing holding it back.)
5. Remaining Pekutherm<sup>®</sup> can be peeled off of the screw. Dispose of the residue safely by quenching in water and/or putting in appropriate waste container.
6. Hand clean remaining tough spots. Measure and check screw for wear and defects.
7. Reassemble machine and return to normal molding.